



## **B+N's Iconic™ Panels: On-Site Cutting Guidelines**

- Using **table saw** (make sure to have a sharp blade before cutting to avoid ragged edges)
- Place the panel with the melamine side facing **DOWN** (back side) and the vinyl side **UP** (front side)
- Score the melamine side (back of panel) 1/16"
- Cut all the way through the panel with the table saw
- Panels should not be cut in a cold environment as it will cause the vinyl to be more brittle and more susceptible to cracking and chipping
- Using **circular saw** (make sure to have sharp blade before cutting to avoid ragged edges)
- Place the panel with the melamine side facing **UP** (back side) and the vinyl side facing **DOWN** (front side)
- Score the melamine side (back of panel) 1/16"
- Cut all the way through the panel with the circular saw
- Panels should not be cut in a cold environment as it will cause the vinyl to be more brittle and more susceptible to cracking and chipping

**Note: A jigsaw is NOT recommended**

B+N Industries, Inc.

**Main offices:**

1409 Chapin Avenue | Burlingame, California 94010 | (800) 350-4127

**New York Showroom and offices:**

420 West 14th St. | New York, New York 10014 | (212) 255-4110

[www.BNind.com](http://www.BNind.com)